

# **PROFILE DESIGN** Installation Instructions Aquarack™

**Tools and materials required: 4mm Allen wrench, Torque wrench**

1. Please use grease (such as Pedro's, Finish Line, Phil Wood, Shimano, etc.) on the threads of all bolts.
2. **⚠ WARNING DO NOT spread apart the Aquarack bracket to install.** To properly install this product one must slide it onto the seatpost. The Aquarack will only work with seatpost sizes of 26.8, 27.0, or 27.2 mm.
3. Double check all bolts for tightness before final assembly.
4. After sliding the Aquarack onto the seat post, adjust to the desired height and tighten the M5 binder bolt to a torque of 25in-lbs (2.8Nm).
5. Double check the hardware for tightness after the first use and periodically thereafter to insure secure attachment.

## **Worldwide Limited Warranty**

Profile Design, LLC (producer / manufacturer) warrants to the original retail purchaser ("you") that the Profile Design product for which they received this warranty is free from defects in material and workmanship for two years from the date of original retail purchase. Profile Design's sole obligation under this warranty is to repair or replace the product, at Profile Design's option. Profile Design must be notified in writing of any claim under this warranty within 60 days of any claimed lack of conformity of the product. FOR WARRANTY DETAILS PLEASE VISIT [www.profile-design.com](http://www.profile-design.com) OR CALL (310) 884-7756 EXT. 161

